



Install isolation barriers, wash station, and negative pressure. Remove water stained/mold growth-impacted ceiling tiles, pipe insulation, and carpet. Clean and disinfect area.

Remove "wet" carpet. Clean and disinfect area.

Install isolation barriers. Remove plaster.

KT Murphy Elementary School

City of Stamford

Stamford, CT

MARK	DATE	DESCRIPTION
PROJECT NO:	S2087	
DATE:	11/19/2018	
FILE:	KT Murphy.dwg	
DRAWN BY:	WAC	
CHECKED:	XX	
APPROVED:	XX	

SCALE: 1/16" = 1'

Figure 2.2 - Growth Removal Work Plan

Install drop cloth. Clean and disinfect growth on AHU, pan and ductwork. Remove foam insulation in pan

AOC-11

AOC-01

AOC-02

AOC-04

Install isolation barriers. Remove wet carpet.

Install isolation barriers, wash station, and negative pressure. Remove "wet" carpet and drywall.

AOC-15

AOC-12

FIRST FLOOR LEVEL

AOC-14

AOC-13

Install isolation barriers, wash station, and negative pressure. Remove mold growth - impacted drywall, carpet, window trim. Clean and disinfect Area.

AOC-16

Install isolation barriers, wash station, and negative pressure. Remove water damaged floor tile/mastic to subfloor, pipe insulation, ceiling tiles, drywall. Clean and disinfect area.

AOC-18

SECOND FLOOR LEVEL

Plot Date: 11/19/2018
 Plot Time: 11:19:20 AM
 Plot User: wechampane
 Tighe & Bond: S:\S2087-Stamford\Drawings\CAD\KT_Murphy.dwg

KT Murphy Elementary School

City of Stamford

Stamford, CT

MARK	DATE	DESCRIPTION
PROJECT NO:	S2087	
DATE:	11/19/2018	
FILE:	KT_Murphy.dwg	
DRAWN BY:	WAC	
CHECKED:	XX	
APPROVED:	XX	

SCALE: 1/16" = 1'

Figure 2.1 - Growth Removal Work Plan